xo|stream

Owner's Manual

www.x-odos.com

Thank you for your confidence in choosing an x-odos product. Your xo|stream will provide you with pure musical enjoyment and we wish you endless hours of listening pleasure.

Your x-odos team

© 2014 - 2018 x-odos® GmbH

x-odos, the x-odos logo, xo|stream are registered trademarks of x-odos GmbH, registered in the EU and other countries.

Table of contents

Legal information 5

Placing 7
- Dimensions: 7

Installation »Quick and easy!« 8
- Overview & Settings 9
  - Options 9
- Library 11
  - Rescan library 11
  - Library - Shares 11
  - Library - USB drive 12
  - Library - Cover extraction 12
- Settings 13
  - »System« 13
  - »Language« 13
  - »Time« 14
  - »Network« 14
  - »WLAN« 15
  - »AirPlay« 16
  - »Music« 17
- Update 18
- Support 19
- Info 20
  - Why to register? 20

Control »Simply easy!« Controlling the xo|stream with iOS 21
- Requirements 21
- Options 21
- Start the xo|stream app on your iPad or iPhone. 22
- Controlling the xo|stream with an iPad 23
- App Settings 25
  - Server Options: 25
  - Cover Images: 25
  - Data: 26
  - Playback: 26
- Queue 27
  - Edit & Save Queue: 27
- Sorting by album 28
  - Track 29
- Sorting by artist 30
- Sorting by title 31

Genre View....32
Playlists....33
External services - Internet radio....34
External services - HIGHRESAUDIO VirtualVault....35
External services - TIDAL....37
What is TIDAL?....37
Can I try out TIDAL for free?....38
On which devices can I use TIDAL?....38
First use of TIDAL....38
External services - Qobuz....41
What is Qobuz?....41
Appendix....44
Declaration of Conformity....44
Declaration of Conformity....45
EU Declaration of Conformity....46

Legal information

Do not allow under any circumstances anyone to modify your x-odos products without first checking with the x-odos GmbH, the responsible distributor or your dealer. Your warranty becomes null and void immediately if unauthorized modifications are made to the products.

Any warranty claim becomes null and void immediately if you open the device.

General notes

Make sure that no liquids can drop or splash onto electrical devices and that no vessels which are filled with liquids, such as vases, stand on the devices.

For your own safety, you should not open your x-odos product.

Warning:

Devices classified under protection class I must be connected to a mains socket outlet with a protective earthing conductor.

This device has been tested and found to fulfil the requirements of current EMC directives and safety regulations as well as, if applicable, the requirement for Class B digital devices according to part 15 of the FCC Rules.

These guidelines and rules are designed to provide reasonable protection against malfunctions and harmful interference in a residential installation. This device generates and uses radio frequency energy. This device could also emit RF energy if

it is not installed and used properly and thus cause interference to radio and television reception. However the possibility of interference in certain installations cannot be ruled out. You can check If this device causes interference to radio and TV reception by switching it on and off as well as by pulling out the main plug. In case this device causes interference, you can try to eliminate them with the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the device and the receiver
- Connect the device to an outlet on a different circuit than the one to witch the receiver is connected
- Consult your x-odos dealer or an experienced radio and television technician

•

Legal information:

To the extent permitted by applicable law, the x-odos GmbH denies any liability for damages that are caused directly, incidentally or indirectly by the use of this product. Regardless of whatsoever cause, neither the x-odos GmbH nor its vicarious agents or its representatives can be held responsible for the loss of data or content stored on an x-odos product.

Modifications are subject to change without notice at any time.

All information in this manual corresponds to our knowledge at the time of publication. Errors and errata excepted.

Placing

Dimensions:

When you place the xo|stream in a shelf, a hifi rack or similar furniture, make sure to maintain a distance of

at least 10 cm above

and

5 cm to the sides.

Sufficient air circulation must be ensured at all times to prevent a damage caused by overheating.

Installation »Quick and easy!«

Connecting to the hifi system and the network

The connections

The xo|stream is equipped with four inputs/outputs.

1. An IEC socket (power connection)
2. 3 x USB ports, for connecting a DAC, external storage or a WiFi dongle
3. A network connection, to control the xo|stream
4. A S/PDIF digital output

Installing the xo|stream is really easy. At first connect the S/PDIF digital output of the xo|stream with your D/A converter, then connect the network cable with the router or switch. Finally you should connect the xo|stream to a 110 to 220 V power outlet using the supplied power cord.

Overview & Settings

The xo|stream has no controls on its front panel except from a power switch in order to keep its appearance as plain and elegant as possible.

Basic configuration over your network with a computer, tablet or smartphone Requirements

- The xo|stream must be connected to the network. See »Connecting to the hifi system and the network«.
- A control unit (computer, tablet, smartphone or similar device) that is connected to the same network as the xo|stream

Options

- Information on the xo|stream
- Network configuration
- Configure system settings
- Enable remote access to your xo|stream, in order to provide prompt assistance by our support team in case of a malfunction (remote support)
- Update the software to the latest version
- Play music that is available on your network

Access http://xo-stream/ on your computer or tablet (on a MacIntosh: http://xo- stream.local/) in order to view or change the settings of your xo|stream.

You get useful information on the current IP address, the stored music and the current temperature of the xo|stream on the web interface's home page.



»Change log« Shows changes which were carried out by updates. Notifications on available updates are displayed here, too.

Library

Under the item »Library« you can find everything concerning your music library. You can add network shares here and check if your USB drive has been embedded successfully.

Rescan library



Click the button »Rescan« in order to add new music to the xo|stream database. The whole library will be re-indexed, depending on the size of the library that process may take a while.

Library - Shares

You can expand the music library of the xo|stream by up to five network shares.



Important note:

The number of the network share is marked green if the network drive has been successfully embedded. The number will be marked red if an error occured.

»Delete« Deletes the configuration of network shares so that they will not be embedded after a restart.

»Host« Enter the IP address or the name of the network resource that you want to use for the backup.

»Path to network share« Enter the path to the network drive on the specified network resource.

»User name« Enter the user name if required for a login, otherwise leave the field empty.

»Password« Enter the password if required for a login, otherwise leave the field empty.

»Type of network share« Choose the type of network share (SMB / NFS / AFP). Usually SMB is correct.

Library - USB drive

Indicates if the USB has been embedded successfully or if an error occured during that process.

Library - Cover extraction

The xo|stream can only show covers correctly if the album folder contains an image named »cover.jpg«. In order to establish this requirement simply, the xo|stream automatically searches for »cover.png« or »folder.png« and converts those files into a JPG image.

In case the album folder does not contain any image file, the xo|stream checks if the meta data of the music files contain a cover image and extracts it. Currently the extraction routine supports the file formats FLAC, M4A and MP3. The results of the extraction process are shown in this log.

Settings

This menu item is used to configure the xo|stream. »Restart« restarts the xo|stream, »Switch off« powers the device down. »Delete settings« resets the xo|stream to factory settings.

»System«

Shows the system services and their current operating status. A green point behind a service name indicates that this service is currently active, a red point indicates inactive services. »Stop« deactivates the service, »Start« activates the service.



»xo|stream Player«	The service for music playback.
»xo|stream DLNA«	DLNA allows other devices to access music via the xo|stream.
»xo|stream AirPlay«	Allows to stream music from an iPhone, an iPad or a Mac to the xo|stream via AirPlay®.

»Language«

Select the language for the setup menu. Currently you can choose from German, English and Russian. Click »Save« to save your selection.

»Time«

By selecting the time zone, the clock of the xo|stream is set automatically. Click »Save« to save your selection.



»Network«

Usually the xo|stream runs with DHCP. In this case the router assigns a network address to the xo|stream. You can also assign a static IP address to the xo|stream.



»System name«	This is the name under which the xo|stream appears on the network.
»Workgroup«	This is the name of the workgroup in which the xo|stream is supposed to be found.
»DHCP«	If DHCP is activated the xo|stream obtains the network settings and the IP address from a DHCP router, usually the main router.
»Static IP«	Must be activated in order to specify and save the following network settings.
»IP address«	Enter the IP address under which the xo|stream is supposed to be accessible on the local network. There are three private IP address ranges: 10.0.0.0 to 10.255.255.255, 172.16.0.0 to 172.31.255.255 and 192.168.0.0 to 192.168.255.255 Usually the local network addresses are located within the range 192.168.xxx.xxx
»Subnet mask«	Specifies the location of other devices connected to your network. Usually the subnet mask is 255.255.255.0
»Gateway«	Usually the standard gateway is the address of your router.
»DNS1«	The Domain Name Service is one of the most important services in many IP- based networks. Its main task is to reply to requests for domain name resolution. If you leave this field empty, fast Open DN Servers will be chosen automatically.
»DNS2«	See »DNS1«.
»DNS3«	See »DNS1«.

»WLAN«

The xo|stream also functions as a WLAN access point if you connect a WLAN adapter via USB. You can specify the network name (»SSID«) and the WLAN password here.



Important note:

Not every adapter is compatible. Consult your dealer prior to a purchase.

»AirPlay«

The xo|stream also functions as an AirPlay® station, allowing to stream music from an iPhone, an iPad or a Mac to the xo|stream.

»Name«	The name under which the xo|stream is shown on AirPlay®-enabled devices.
»Password«	Enter the password or leave this field empty if you do not want to use a password.
»Volume«	Select »Yes« if you want to control the volume of the stream with the source, otherwise select »„No«.

»Music«



»Name«	Either choose the internal DAC or an USB DAC for the signal output.
»Output«	Some USB DACs offer various outputs which can be selected by software, usually »0« is used.
»Auto-Update«	The xo|stream will automatically scan the music library for changes if you choose »Yes«.
»Buffer size«	Allows to define the buffer size for music playback.
»Buffer«	Allows to define the minimum filling quantity of the buffer for playback.
»Resample«	Allows to define a fixed sample rate for playback.

Update

You can obtain software updates for your xo|stream under this item. Therefore click on the button »Start update«. You should restart the xo|stream after an update, click »Restart« in order to do so. If the xo|stream does not restart keep the power button on the front panel pressed until the light around the button turns off.

»Start update«	Click »Start update« to search for updates and to install them.
»Restart«	Click »Restart« to restart the xo|stream.
»Switch off«	Click »Switch off« to switch the xo|stream off.
»Entire log«	Click „Entire log“ to view all update log entries.
»Clear log«	Click »Clear log« to delete all update log entries.

Support

In case you require assistance, the remote maintenance function provides a convenient way to get a prompt solution. In order to use this option, you will have to enable remote access for each support session, allowing our support team to access your xo|stream.

The remote access will be automatically terminated if you restart the xo|stream or click onto the button »Stop«.



Click the button »Start« to start the remote maintenance. If you use the remote maintenance for the first time, the xo|stream will install the remote maintenance routine first. After a short while the message »Remote maintenance active« is shown, as well as an IP address with the format 10.8.0.xxx. Our support staff member will ask you for this IP address, it is required to get full access to your xo| stream.

Info

Here you can register your xo|stream, if not yet registred or review the registration info.

Important note:

Once the xo|stream is registred you have to send us a notice, if you sold the xo|stream with the name of the new owner.

Important note:

Please be aware the guarantee is not transferable. In case of changed ownership the legal warranty applies from the date of purchase of the first owner.

Why to register?

- the registration extends the guarantee time from 6 months to 2 years
- you will be noticed if there are hardware upgrades available
- your ownership will be confirmed
- be the first to know about new product and new offer

Control »Simply easy!« Controlling the xo|stream with iOS

Download the xo|stream control app from the App Store.

xo|stream Pad (iPad) https://itunes.apple.com/de/app/xo-stream-pad/id1103612511?mt=8

http://www.x-odos.com/xo-stream/download.html

xo|stream Phone (iPhone) https://itunes.apple.com/de/app/xo-stream-phone/id1105338931?mt=8

http://www.x-odos.com/xo-stream/download.html

Requirements

- The xo|stream must be connected to the network. See »Connecting to the hifi system and the network«.
- A proper installation of the app onto an iOS device.
- The iOS device must be connected to the same network as the xo|stream.

Options

This easy-to-use app allows for the whole music playback functionality. That includes among other options:

- Start and stop playback
- Create playlists
- View the music library
- Listen to internet radio stations
- Purchase music at HIGHRESAUDIO
- Access the streaming service TIDAL
- Access the streaming service Qobuz

Start the xo|stream app on your iPad or iPhone.

When you start the app for the first time, you will have to configure the connection to the xo|stream.



Normally the app finds the xo|stream automatically. In that case tap onto »xo| stream« below the header »DISCOVERED XO|STREAM SERVERS« to confirm the device and then tap »Done«.

In case the xo|stream is not found automatically, choose »Add your xo|stream manually«. First name the connection, e.g. »xo|stream«. Enter under »IP address of your xo|stream« either the IP address or »xo-stream.local«. Finally tap onto »Save«.

Ready. Now your xo|stream appears in the server list. The antenna symbol indicates if the xo|stream is connected (shown darkly) or if currently no connection can be established (shown lightly).

Controlling the xo|stream with an iPad

After the app started, it shows an overview on your albums. With the default setting the albums are shown in alphabetical order, sorted by album name. The app works both in portrait and in landscape mode.



* The remote control is an optional accessory for the xo|stream and the xo|stream.

** External Services are Radio, TIDAL, Qobuz and Highresaudio. Please note that some of them are fee-based services, additional fees may apply.

The grey area at the upper edge of the screen contains the control symbols for music playback:



»Previous title«	Skips to the previous title in the queue.
»Stop«	Stops the playback. Double-tap to delete the queue.
»Play / Pause«	Starts or pauses playback.
»Next title«	Skips to the next title in the queue.
»Repeat«	Repeats the queue.
»Progress bar«	Shows the playback progress. On the left you can read the past playback time, on the right the duration of the current title is shown. Move the white point to navigate within the title. Above the progress bar the name of the current title is shown, below the name of the artist and the album.
»Shuffle«	Plays a random title from the queue.
»xo|stream«	This lettering hides some settings and information which are described in detail within the previous chapter. »Start« links to the home page which is also available under http://xo-stream/index.php. »Library« allows for access to connected network resources. Tap onto »Setup« in order to configure the xo|stream. Tap onto »Update« in order to update the xo|stream.

App Settings

The app settings can be accessed by tapping onto the gearwheel symbol, shown buttom left of the app screen.



»About xo|stream Pad« Shows the version number.

»Help« Shows a brief help text.

Server Options:

»Rescan app database« Copies the database entries from the xo|stream onto the server.

»Refresh xo|stream database« Re-indexes the music on the xo|stream.

Cover Images:

»Rescan cover images«

Album covers are cached on the iPad. In order to recognise changes the image source has to be rescanned.

Data:

»Artists«	Choose if artists are shown in the list which are only found in compilations (albums with various artists).
»Artist capital letter«	All artists begin with a capital letter - but in that case »ABBA« is shown as »Abba«.
»Album«	Choose if the albums are sorted by album name or by folder name. The difference only appears on network drives.
»Album sorting«	Albums can be sorted either by album name or by artist -> album name. If albums are sorted by artist all albums of one artist are shown together.
»Refresh cash automatically«	Activate or deactivate the automatic synchronisation of the app database with the xo|stream database.

Playback:

»Response to tap«	You can define what happens if you tap onto an album or onto a title.
»Play now«	Plays the selection immediately.
»Play next«	Adds the selection to the queue, following the current title.
»Play only«	Replaces the queue by the selection.
»Add to queue«	Adds the selection to the end of the queue.
»Remove«	Removes the current title from the queue. This function is especially useful in case the shuffle play is activated.
»»Shake«	You can define what happens if you shake the iOS device:

None	no action is executed
1 random album	is added to the queue
10 random titles	are added to the queue
25 random titles	are added to the queue
50 random titles	are added to the queue
100 random titles	are added to the queue

Queue

The queue shows the current title as well as all upcoming and previous titles. In order to see more titles in larger queues, you can hide the cover display below the list. Swipe down with two fingers on the list in order to that. If you swipe up with two fingers the cover is shown again.

Tap onto a title in the queue to play the title immediately.

If you touch and hold a title name further options are shown:

»Remove from queue«	Removes the title from the queue.
»Add to favourites«	Adds the title to the playlist »Favourites«. This playlist is shown under the item »Playlists«.
»Play next«	Adds the title following the current title.
»More from this artist«	Switches to the item »Artist« and shows all music from this artist in your library. This function does not work concurrently witch an artIst search.

Edit & Save Queue:

The button »Edit« is shown below the queue. It allows for additional options.

»Edit queue«	Tap onto »Edit queue« in order to move titles within the queue and consecutively remove several titles from the queue quickly. In order to remove titles, tap onto the red point in front of the title name, then select »Remove« behind the title name to confirm. In order to move a title, touch and hold the three horizontal lines behind the title name and then move them to the preferred position in the queue.
»Save queue«	Tap onto »Save queue« in order to save the queue as a playlist. Please note that you cannot overwrite existing playlists with this function. Thus you will have to enter a new name.
»Delete queue«	Tap onto »Delete queue« in order to remove all titles from the queue. Alternatively you can double-tap »Stop« to do so.
»Play whole library«	Adds all music from your library to the queue and starts playback.
»Skip to current title«	Skips to the beginning of the current title.

Sorting by album

This function presents all album covers of the xo|stream music library in a grid pattern. Below each cover, the album name and the artist name is shown. You can switch between two sort sequences in the settings:

1. The albums are sorted by album name.
2. The albums are first sorted by artist name and then by album name for each artist.



You can open an album simply by tapping onto the cover image. If you tap onto the »Play« symbol top right the whole album is added to the queue. If you tap onto one title only this title is added to the queue.

The search above the cover images only searches for album names.

If you touch and hold an album cover a menu opens, allowing for various options.

»Play now«	Adds the album to the current position of the queue and plays it immediately.
»Play next«	Adds the album to the queue, following the current title.

»Play only«	Replaces the queue by this album.
»Add to queue«	Adds the album to the end of the queue.
»Delete album«	Deletes the album after a confirmation prompt. The deletion is irreversible.

Track

If you touch and hold an track name a menu opens, allowing for various options.



»Play now«	Adds the title to the current position of the queue and plays it immediately.
»Play next«	Adds the title to the queue, following the current title.
»Play only«	Replaces the queue by this title.
»Add to queue«	Adds the title to the end of the queue.
»Delete title«	Deletes the title after a confirmation prompt. The deletion is irreversible.

Sorting by artist

Shows a list of all artists. Depending on your settings, artists which are only found in compilations are shown as well.

The search above the artist list only searches for artist names.

If you tap onto an artist name all albums are shown which include at least one title by this artist. This album view responses as described under »Sorting by album«.



If you touch and hold an artist name a menu opens, allowing for various options.

»Play now«	Adds all titles by this artist to the current position of the queue and plays it immediately.
»Play next«	Adds all titles by this artist to the queue, following the current title.
»Play only«	Replaces the queue by all titles of this artist.
»Add to queue«	Adds all titles by this artist to the end of the queue.

Sorting by title

This view shows all titles of all artists in your music library in alphabetical order. The search above the title list only searches for title names.

If you tap onto a title this title is added to the queue and played immediately, unless you defined a different response in the settings.



Touch and hold a title name to choose at which position in the queue the title is added.

»Play now«	Adds the title to the current position of the queue and plays it immediately.
»Play next«	Adds the title to the queue, following the current title.
»Play only«	Replaces the queue by this title.
»Add to queue«	Adds the title to the end of the queue.

Genre View

This view shows an alphabetical list of all genres in your music library. The search above the genre list only searches for genre names.

If you tap onto a genre name all albums are shown which are tagged with this genre. This album view responses as described under »Sorting by album«.



If you touch and hold a genre name a menu opens, allowing for various options.

»Play now«	Adds all titles of this genre to the current position of the queue and plays them immediately.
»Play next«	Adds all titles of this genre to the queue, following the current title.
»Play only«	Replaces the queue by all titles of this genre.
»Add to queue«	Adds all titles of this genre to the end of the queue.

Playlists

This view shows an alphabetical list of all saved playlists.

If you tap onto a playlist this playlist is added to the end of the queue. In order to only play the selected playlist, you have to clear the queue first. The fastest way to clear the queue is to double-tap »Stop«.

You can delete playlists using the button »Edit« shown top right.

External services - Internet radio

Legal information:

Internet radio stations are external services. These external services are not offers of the x-odos GmbH. Thus the x-odos GmbH does not assume any warranty for their availability or their compatibility with products and services offered by the x- odos GmbH. The x-odos GmbH solely connects to services of respective third- party suppliers in order to allow for their use with the xo|stream.

This view shows some internet radio stations.

If you tap onto a radio station this station is added to the queue and played immediately, unless you defined a different response in the settings.

Touch and hold a station name to mark this station as a favourite. In case stations are marked as favourites, the radio service always starts witch an overview on your favourites.

You can search for station names in the search bar. Additionally filters allow for a sorting by streaming quality, genre and country. You can apply several criteria at the same time.

Tap onto »Reset filters« in order to get a general view again.

External services - HIGHRESAUDIO VirtualVault

Legal information:

HIGHRESAUDIO is a fee-based service, additional fees may apply. HIGHRESAUDIO services are not offers of the x-odos GmbH. Thus the x-odos GmbH does not assume any warranty for their availability or their compatibility with products and services offered by the x-odos GmbH. The x-odos GmbH solely connects to HIGHRESAUDIO services in order to allow for their use with the xo|stream.

HIGHRESAUDIO VirtualVault is a streaming service which exclusively offers uncompressed, lossless streams of audiophile recordings from various genres, with the highest possible quality in terms of sample rate.

Important note:

Prior to a purchase, make sure that both the xo|stream and your D/A converter are compatible with the format of the chosen product or service.

Legal information:

The x-odos GmbH does not assume any warranty for the compatibility of products and services offered by the x-odos GmbH with products or services offered by HIGHRESAUDIO or other third-party suppliers.

HIGHRESAUDIO exclusively offers hi-res music downloads with »Studio Master Quality«. Depending on the product, the files are provided in the formats FLAC, ALAC, DSD and DXD-FLAC, with sample rates between 44.1 kHz and 384 kHz. The files can be downloaded immediately after purchase, a physical medium is not available!

VirtualVault allows to stream the music you purchased at HIGHRESAUDIO to the xo| stream. Currently the streaming supports PCM files with a maximum resolution of 24 Bit/192 kHz. DSD formats are currently not supported.



When you first use HIGHRESAUDIO with the xo|stream app you will have to enter your HIGHRESAUDIO user name (i.e. your e-mail address) and the HIGHRESAUDIO password you set during the subscription under http://www.highresaudio.com/. The login data are saved both on the xo|stream and on your iPad, respectively your iPhone. Therefore you have to login at HIGHRESAUDIO on each iOS device you want to use.

After successful login you have access to your HIGHRESAUDIO VirtualVault music archive, allowing to stream purchased albums to your xo|stream.

When you tap onto an album cover, you have the option to add either the whole album or individual titles to the queue. Tap onto »+« in order to do so. If HIGHRESAUDIO VirtualVault provides a booklet the button »Booklet« appears dark- grey. Tap onto this button in order to view the booklet within in the app.

External services - TIDAL

Legal information:

TIDAL is a fee-based service, additional fees may apply.

TIDAL services are not offers of the x-odos GmbH. Thus the x-odos GmbH doesnot assume any warranty for their availability or their compatibility with products and services offered by the x-odos GmbH. The x-odos GmbH solely connects to TIDAL services in order to allow for their use with the xo|stream.

Important note:

The xo|stream is only compatible with the TIDAL hi-fi subscription. Currently the x- odos GmbH only supports lossless streaming services.

What is TIDAL?

TIDAL is an add-free music streaming service, offering lossless CD quality and extensive editorial expertise. TIDAL allows for access to more than 40 million titles.

Can I try out TIDAL for free?

Yes, if you register at TIDAL a free trial period is offered. You can cancel your account at any time during that period.

On which devices can I use TIDAL?

TIDAL works on smartphones, tablets, computers and on your xo|stream.

First use of TIDAL



When you first use TIDAL with the xo|stream app you will have to enter your TIDAL user name and the TIDAL password you set during the subscription under http:// www.tidal.com/. The login data are saved both on the xo|stream and on your iPad, respectively your iPhone. Therefore you have to login at TIDAL on each iOS device you want to use.

Troubleshooting

If the xo|stream does not play titles from TIDAL login on your iPad again and make sure you have network access onto the xo|stream. Restart the xo|stream afterwards to be on the safe side.

After successful login you have access to the TIDAL music archive.

»New« shows all new playlists, albums and titles that TIDAL offers. If you tap onto an album or a playlist its content is displayed. You can choose to either play the entire album, respectively the entire playlist, or to play individual titles. Touch and hold an album cover in order to mark the album as a TIDAL favourite or to add the album to a TIDAL playlist.

»Mark as TIDAL favourite«	Adds the title, album or playlist to your favourites under the item »My music«.
»Add to TIDAL playlist«	Adds the title, album or playlist to a playlist under the item »My music«.

The menu item »Playlists« shows playlists created by TIDAL, sorted by categories. Tap onto a category name in order to view all available playlists of that category.

The menu item »Genres« shows the genres provided on TIDAL. Tap onto a genre name in order to view all available albums of that genre.

Under »My music« you can find:

»My playlists«	Shows the playlists which you created yourself on TIDAL. Tap onto a playlist in order to view its content and to play either the whole playlist or individual titles. Touch and hold a playlist cover in order to edit or to delete that playlist.
»Favourite playlists«	Shows those playlists created by TIDAL, which you marked as favourites. Tap onto a playlist in order to view its content and to play either the whole playlist or individual titles. Touch and hold the cover of a favourite playlist in order to remove that playlist from your TIDAL favourites or to add that playlist to one of your own playlists.
»Favourite artists«	Shows those artists, which you marked as favourites. Tap onto an artist name in order to view all available albums of that artist. Touch and hold an artists' image in order to remove that artist from your TIDAL favourites.

»Favourite albums«	Shows those albums, which you marked as favourites. Tap onto an album in order to view its content and to play either the whole album or individual titles. Touch and hold the cover of a favourite album in order to remove that album from your TIDAL favourites or to add that album to one of your own playlists.
»Favourite titles«	Shows those titles, which you marked as favourites. Tap onto a title in order to add that title to the queue and play it. Touch and hold the cover of a favourite title in order to remove that title from your TIDAL favourites or to add that title to one of your own playlists.

The loupe symbol in the menu bar allows for the use of the TIDAL search. Enter a search item and tap onto »Search« to confirm. Subsequently results from the categories albums, artists or titles are shown. Tap onto the three horizontal points behind a category name in order to view further results.

External services - Qobuz

Legal information:

Qobuz is a fee-based service, additional fees may apply.

Qobuz services are not offers of the x-odos GmbH. Thus the x-odos GmbH doesnot assume any warranty for their availability or their compatibility with products and services offered by the x-odos GmbH. The x-odos GmbH solely connects to Qobuz services in order to allow for their use with the xo|stream.

What is Qobuz?

Qobuz was formed in 2008, the goal was to offer the digital world the aspects of music fandom that audiophiles, those who love music best, have always cherished. For Qobuz, this meant quality sound, quality editorial, and a freedom of choice that wholly excludes bias. As a result of Qobuz diverse collective culture and musical education, the business catered to artists old and new.

Qobuz designed a service that catered to highly specialized music lovers, all over the world. Unlimited access to millions of tracks

Be free to explore our catalogue of over 40 million titles, with more than 70,000 Hi-Res 24-bit albums.

First and foremost, Qobuz offers music in the best condition possible. That is to say, the music collection consists of recordings as close to the original studio recording as you can get.

Indeed, Qobuz was the first music service to offer CD-Quality, 16 bit/44kHz files for streaming and it's the first music service in the world to offer 24-Bit Hi-Res files for streaming.

When you first use Qobuz with the xo|stream app you will have to enter your Qobuz user name and the Qobuz password you set during the subscription under http://www.qobuz.com/. The login data are saved both on the xo|stream and on your iPad, respectively your iPhone. Therefore you have to login at Qobuz on each iOS device you want to use.



After successful login you have access to the Qobuz music archive.

»Albums« shows all new albums that Qobuz offers. You can see, if the Album is available in Hi-Res Audio by a small sticker on the album cover. By using the button »Genres« on the upper left you can filter the »albums« by a genre.

If you tap onto an album or a playlist its content is displayed. You can choose to either play the entire album, respectively the entire playlist, or to play individual titles. Touch and hold an album cover in order to mark the album as a Qobuz favourite.

»Add to favorites on qobuz«	Adds the title, album or playlist to your favourites under the star icon.

The menu item »Playlists« shows playlists created by Qobuz.

Under the start icon on the upper right the favorites can be found.

»Favourite Artists«	Shows those artists, which you marked as favourites. Tap onto an artist name in order to view all available albums of that artist. Touch and hold an artists' image in order to remove that artist from your Qobuz favourites.
»Favourite Albums«	Shows those albums, which you marked as favourites. Tap onto an album in order to view its content and to play either the whole album or individual titles. Touch and hold the cover of a favourite album in order to remove that album from your Qobuz favourites or to add that album to one of your own playlists.
»Favourite Tracks«	Shows those titles, which you marked as favourites. Tap onto a title in order to add that title to the queue and play it. Touch and hold the cover of a favourite title in order to remove that title from your Qobuz favourites or to add that title to one of your own playlists.

The loupe symbol in the menu bar allows for the use of the Qobuz search. Enter a search item and tap onto »Search« to confirm. Subsequently results from the categories albums, artists or titles are shown. Tap onto the three horizontal points behind a category name in order to view further results.

Appendix

Declaration of Conformity

We, x-odos GmbH, Schwaighofstr. 2, 79100 Freiburg, Germany

declare under our sole responsibility that the product

Category Name: Music Server

Model Name: xo|stream

to which this declaration relates is in conformity with the following standard(s) or other normative document(s)

Art. 3.1(a): EN 60065:2002 + A1:2006 + A2:2010 + A11:2008 + A12:2011
EN 62311:2008

Art. 3.1(b): EN 55013:2001 + A1:2003 + A2:2006, EN 55022:2010 Class B,
EN 55020:2007 + A11:2011, EN 55024:2010,
EN 61000-3-2:2006 + A1:2009 +A2:2009, EN 61000-3-3:2008

following the provisions of 1999/5/EC, R&TTE directive(s).

Germany, 30th July, 2014

ppa.

Christof Poschadel, Managing Director

Declaration of Conformity

We, x-odos GmbH, Schwaighofstr. 2, 79100 Freiburg, Germany

declare under our sole responsibility that the product

Category Name: Music Server

Model Name: xo|stream

to which this declaration relates is in conformity with the following standard(s) or other normative document(s)

(EC) No 1275/2008

following the provisions of 2009/125/EC, Ecodesign directive(s).

Germany, 30th July, 2014

ppa.

Christof Poschadel, Managing Director

EU Declaration of Conformity

Unique identification of the Declaration of Conformity:

201407001

Name and address of the manufacturer or his authorised representative:

x-odos GmbH, Schwaighofstr. 2, 79100 Freiburg, Germany

This declaration of conformity is issued under the sole responsibility of the manufacturer:

x-odos GmbH, Schwaighofstr. 2, 79100 Freiburg, Germany

Object of the declaration:

Model name:	Category name:
xo|stream	Music Server

The object of the declaration described in point 4 is in conformity with:

2011/65/EU (RoHS)

References to the relevant harmonised standards used, or references to the specifications in relation to which conformity is declared:

EN 50581:2012

Additional information:

Signed for and on behalf of: x-odos GmbH

Germany, 30th July, 2014

ppa.